



TO INSTALL LOCK:-  
RAISE FWD END OF LOCK & INSERT AFT END  
IN SOCKET. LOWER FWD END MOVING YOKE AFT  
TO NEUTRAL POSITION. PUMP PINS INTO HOLES  
IN YOKE. STRAP LOCK TO PILOTS SEAT SUPPORT.

TO RELEASE LOCK:-  
RELEASE STRAP. RAISE FWD END OF LOCK  
FROM YOKE. MOVE YOKE FWD TO CLEAR  
DISENGAGE AFT END OF LOCK FROM SOCKET.

H-206

LEV	ALTERATION	DATE	BY	LEV	ALTERATION	DATE	BY
A	REWORKING LUGS ON BEAMS						
	RESEAL CRACKS, SPRAYED WITH S						
	PLASTER						
B	REPAINTING 1" WOOD ON BEAMS						
	PAINTING						

[illegible]